







# LAGOS

winkelkast OK  
buffetschrank gross  
vaisselier  
showcabinet








MADE BY  
**wood**


Produced by De Eekhoorn Woodworkings BV










14




Eerst achterwand centreren, vast spijkeren en dan pas schroeven.  
Zuerst Rückwand zentrieren, festnageln und danach festschrauben.  
Commencer par centrer la paroi arrière, la fixer à l'aide de clous et ensuite la visser.  
Backpanel centre, nailed first and screwed thereafter.








15



4x




16









LAGOS

winkelkast BK  
buffetschrank gross  
vaisselier  
showcabinet






|                                                                               |                                                                             |                                                                           |                                                                             |                                                                       |                                                                                        |
|-------------------------------------------------------------------------------|-----------------------------------------------------------------------------|---------------------------------------------------------------------------|-----------------------------------------------------------------------------|-----------------------------------------------------------------------|----------------------------------------------------------------------------------------|
| <div> <div>Ø 15 MM</div> <div>A</div> <div>000102<br/>26 x</div> </div>       | <div> <div>24 x 8,5 MM</div> <div>B</div> <div>000130<br/>22 x</div> </div> | <div> <div>Ø 8x35 MM</div> <div>C</div> <div>000601<br/>6 x</div> </div>  | <div> <div>3,5 x 35 MM</div> <div>D</div> <div>000219<br/>10 x</div> </div> | <div> <div></div> <div>E</div> <div>000316<br/>100 x</div> </div>     | <div> <div>1489 MM</div> <div>F</div> <div>000901<br/>4 x</div> </div>                 |
| <div> <div>3,5x44MM</div> <div>G</div> <div>000239<br/>27 x</div> </div>      | <div> <div></div> <div>H</div> <div>000636<br/>4 x</div> </div>             | <div> <div>M4 x 17 MM</div> <div>J</div> <div>000235<br/>8 x</div> </div> | <div> <div>HETT30</div> <div>K</div> <div>000429<br/>6 x</div> </div>       | <div> <div>HETT30</div> <div>L</div> <div>000430<br/>6 x</div> </div> | <div> <div>Ø14 KniezugsWit</div> <div>M</div> <div>000373/000369<br/>24 x</div> </div> |
| <div> <div>Safety balance</div> <div>N</div> <div>000356<br/>1 x</div> </div> |                                                                             |                                                                           |                                                                             |                                                                       |                                                                                        |







8



9



10

