

Assembly Insturction

410016 CABINET BROOKE



STEP1



STEP2



A1



A:2PCS

A2



B:2PCS