




• The device setup is complete. You will hear two beeps when the device setup completes.

iCam / iBabi / iCare







• The green LED remains on when Wi-Fi is working properly.

Press " ▶ " to view.



20

29

Control device

iSensor / Patio



By sliding your screen left or right

Remotely pan the device anywhere by sliding your smartphone screen in the direction you want the device to turn.

LED indication

Blue LED:


- The LED is stable when you power on the device.
- The LED flashes once per second when the QR scan is in progress.
- \bullet When LED is flashing twice per second, the device is in use and someone is actively viewing it.
- When LED is flashing 3 times per second, the setup process was successful.

Green LED:

- When LED is flashing once per second, the device is trying to connect to a Wi-Fi AP router.
- When LED is constant, the device is connected to Wi-Fi and working properly.

22

19




If connection fails

Please check:


- 1. Is the device powered on?
- 2. Is the device's Wi-Fi connected? (Green LED should be lit)
- 3. Is a new Wi-Fi router required? (Press " ** ")

24



First, make sure the device is powered on and the calibration is completed There is a small RESET hole. Press and hold for about 5 seconds until the blue LED flashes. All settings of previously stored in the device will be erased, and it will be restored to the factory default.

After 25 seconds, the device will start a calibration mode by rotating itself. (for remote models) 25




- 1. Connect your phone to your router.
- 2. Press and hold router's WPS button.
- 3. Press and hold WPS or ** button on the device for 5 seconds or longer. When the green LED flashes, it indicates that the device has entered WPS mode.
- 4. Please follow App instructions step-by-step.

within 60 seconds.

Operating temperature iCamPRO / iCamPRO Deluxe Remove the label before use. Operating temperature: 32 - 95°F (0 - 35°C), indoor use only


[Installation Instructions] iCamPRO Deluxe Fig.1. Fig.3. How to remove the holder. Fig.1. Rotate anticlockwise to remove Deluxe from the light socket. Fig.3. Push the holder away from the "Amaryllo" sign and speaker to remove the iCamPRO from its holder. 28



Do Not Manually Twist!


Installation Instructions


- 1. Choose a location offering you the best viewing angle. Make sure that an electric outlet is within 2 meters.
- 2. Use pencil to mark hole locations. Make sure holes are slightly smaller than anchors. 3. Insert anchors to wall and secure holder to wall with screws.





- Fig.1. Choose a location offering you the best viewing angle. Make sure that an $\,$ electric outlet is within 2 meters. Use pencil to mark hole locations. Make sure holes are slightly smaller than anchors. Insert anchors to wall and secure holder to wall with screws
- Fig.2. Align iCamPRO to the holder through the four hooks. Secure iCamPRO to the holder with a screw as shown.
- Fig.3. Adjust the angle of the holder and then tighten the hinge screw.






How to use iCare remote control

iCare

- Fig.1. When an emergency occurs, press and hold the button until you hear a beep $\,$ to send out urgent notification alert. You must be within 10 meters to enable the urgent call alert. Wait 3 seconds to press and hold the button again to disable.
- Fig.2. For best transmitting range, don't let your fingers block the antenna on the top of the transmitter as shown.



- * Warranty is voided if product is open.
- * Please visit our website www.amaryllo.eu to view our warranty policy.